


Pin out of the connector of the ribbon cable

North Side



South Side

	South Side	North Side
1	SW1	SW2
2	SW3	SW4
3	SW5	SW6
4	SW7	SW8
5	GND	N/C
6	GND	N/C
7	GND	N/C
8	GND	N/C
9	LED1	LED2
10	LED3	LED4
11	LED5	LED6
12	LED7	LED8
13	GND	N/C
14	GND	N/C
15	GND	N/C
16	GND	N/C
17	CLK	N/C
18	N/C	N/C
19	N/C	PULSE
20	N/C	N/C